




FuranFlex standardised läbimõõdud



FuranFlex Classic	FuranFlex RWV
mm	mm
80	100
90	110
100	120
110	130
120	140
125	150
130	160
140	170
150	180
160	190
170	200
180	225
190	250
200	275
225	300
250	325
275	350
300	375
325	400
350	425
375	450
400	475
425	500
450	550
475	600
500	650
550	700
600	750
650	800
700	
800	
900	
1000	

$$\text{FuranFlex Classic } D_{\max} = 0,9 \cdot \frac{A + B + C + D}{3,14}$$

$$\text{FuranFlex RWV } D_{\max} = \left(0,9 \cdot \frac{A + B + C + D}{3,14} \right) - 10$$



*kõik mõõdud millimeetrites